




INSTRUKCJA BEZPIECZEŃSTWA,  
MONTAŻU I UŻYTKOWANIA  
**STOPER BRAMOWY  
DO PRZYKRĘCENIA – PSG**



	A	B	H	H1
61.091	158	138	50	26
61.092	120	100	43	20

**Kod Produktu:** (61.091, 61.092)

**Kod CN:** 8302 49 00

**Kod PKWiU:** 25.72.14.0

**Materiał:** Stal elektrogalwanizowana,  
Stal S235JR+AR

### #1 PRZEZNACZENIE | ZASTOSOWANIE

Stoper do bram skrzydłowych to wytrzymały element służący do zabezpieczania bram przed nadmiernym odchyleniem.

Jego stalowa, pokryta cynkiem konstrukcja stabilizuje bramę w pozycji zamkniętej i poprzez zapobieganiu zbyt niemu wysunięciu skrzydeł na zewnątrz zapewnia ochronę zawiasów bramy przed uszkodzeniami.

### #2 BEZPIECZEŃSTWO

**Używanie odpowiednich narzędzi:** podczas pracy z elementami stalowymi należy korzystać z profesjonalnych narzędzi zgodnych z wymogami BHP.

**Zabezpieczenia osobiste:** montaż i konserwacja wymagają stosowania rękawic ochronnych, okularów oraz odzieży odpornej na iskry (np. podczas spawania).

**Stabilność konstrukcji:** montaż należy przeprowadzać na stabilnym, równym podłożu, z odpowiednim zabezpieczeniem przed przypadkowymi przesunięciami elementów.

**Ostrożność przy obciążeniach:** unikaj przeciążenia konstrukcji ponad wskazania producenta.

### #3 INSTRUKCJA MONTAŻU

**Montaż:** do przykręcenia na stabilnym, równym podłożu, w punkcie zbiegu skrzydeł.

**Kontrola montażu:** sprawdź stabilność, położenie elementu przed zakończeniem prac.

### #4 EKSPLOATACJA | KONSERWACJA

**Elementy podlegające konserwacji:** śruby mocujące.

**Regularne przeglądy:** raz na pół roku zaleca się kontrolę stanu technicznego, obejmującą elementów mocujących w podłożu oraz warstwy ochronnej.

Zaleca się sprawdzenie potencjalnych deformacji śrub mocujących, oraz stabilność mocowania stopera bramowego.

### #5 UTYLIZACJA I OCHRONA ŚRODOWISKA

Zużyte lub uszkodzone elementy stalowe należy przekazywać do punktów recyklingu metali, zgodnie z obowiązującymi prawami w kraju instalacji.

### #6 UWAGI | WSKAZÓWKI

W przypadku trudności z montażem lub konserwacją zaleca się konsultację z fachowcem.

Przestrzeganie niniejszej instrukcji zapewni dłuższą żywotność i bezpieczeństwo użytkownika produktu.

Producent nie ponosi odpowiedzialności za szkody wynikające z niewłaściwego użytkowania lub montażu elementów.

#### Producent:

**POSTAL STEEL GROUP POLSKA Sp. z o.o.**


ul. Sowie 6 | Park Przemysłowy „Sowie”

62-080 Tarnowo Podgórne, Polska

+48 61 652 59 00 | info@postal.pl | postal.pl



SAFETY INSTRUCTIONS  
INSTALLATION AND USE  
**SCREW-ON GATE STOPPER – PSG**



	A	B	H	H1
61.091	158	138	50	26
61.092	120	100	43	20

**Product Code:** (61.091, 61.092)

**CN Code:** 8302 49 00

**PKWiU Code:** 25.72.14.0

**Material:** Electro-galvanized steel,  
S235JR+AR steel.

**#1 PURPOSE | APPLICATION**

Swing gate stop is a sturdy element used to protect gates from excessive deflection.

Its zinc-coated steel construction stabilizes the gate in the closed position and, by preventing the wings from extending too far outward, ensures that the gate hinges are protected from damage.

**#2 SAFETY**

**Using the right tools:** when working with steel components, use professional tools that comply with health and safety requirements.

**Personal protection:** installation and maintenance require the use of protective gloves, goggles, and spark-resistant clothing (such as when welding).

**Structural stability:** installation should be carried out on a stable, level surface, with adequate protection against accidental displacement of components.

**Caution with heavy loads:** avoid overloading the structure beyond the manufacturer's indications.

**#3 INSTALLATION INSTRUCTIONS**

**Installation:** to be screwed on a stable, level surface, at the point where the wings converge.

**Installation inspection:** check the stability, position of the component before completing the work.

**#4 OPERATION | MAINTENANCE**

**Components subject to maintenance:** fixing screws.

**Regular maintenance:** once every six months, it is recommended to inspect the technical condition, including fixing elements in the ground and the protective layer.

**#5 DISPOSAL AND ENVIRONMENTAL PROTECTION**

Dispose of used or damaged steel components to metal recycling centers in accordance with applicable laws in the country of installation

**#6 NOTES | TIPS**

If you encounter difficulties with installation or maintenance, consult a professional.

Following this instruction will ensure longer product life and safe usage.

The manufacturer is not liable for damages resulting from improper use or installation of the elements.

**Producer:**

**POSTAL STEEL GROUP POLSKA Sp. z o.o.**

Sowia 6 | Industrial Park „Sowia”

62-080 Tarnowo Podgorne, Polska

+48 61 652 59 00 | info@postal.pl | postal.pl